

SAFETY FIRST!

Please follow all the safety precautions listed below for safety and to reduce the risk of injury or electrical shock.

- Read this Instruction Manual carefully to maximise this appliance's performance and keep for future reference.
- This appliance is not intended for commercial use or any other uses than its intended use.
- Always ensure that your power supply voltage matches this appliance's rating label.
- Do not kink or wrap the mains cable and plug around the appliance, as this may cause the insulation to weaken and split, particularly where it enters the appliance.
- Ensure the mains cable is fully extended before use and arrange it so that it is not in contact with any part of the appliance.
- Do not pull on the mains cable. Never move, carry or hang the appliance by the mains cable.
- Always position the appliance with the mains plug in an accessible position and avoid the use of an extension cables as they may overheat and create a potential fire risk.
- Never position the appliance below a mains socket.
- The appliance must have a minimum 50 cm clearance around all sides of the appliance.
- Ensure that the unit is used on a stable and level surface. If the floor surface is uneven there is a risk that the appliance could tip over. Also, excessive vibration and noise may occur. If the appliance should be accidentally tipped over, please immediately disconnect from the power supply.
- Do not use the appliance in wardrobes or near fabrics or clothing. Do not stand the appliance on deep pile carpets.
- Do not use the appliance in areas where petrol, paints or other flammable substances are used or stored.
- Do not use in very dusty areas as dust may accumulate on the heating elements and cause overheating.
- Do not use if there are any visible signs of damage to the appliance.
- Do not operate the appliance in direct sunlight, near heat sources, humid environments or in places near water or other liquids such as bathrooms, shower or swimming pool.
- Do not operate with wet hands or spill water or other liquids on to the appliance, the mains cable or plug.
- Children should be supervised to ensure that they do not play with the appliance. Do not place the appliance in places that are easy to reach by children.
- Always unplug the appliance when not in use.
- For safety reasons a broken or damaged mains cable may only be replaced by the manufacturer or a similarly qualified person.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instructions concerning the use of the appliance by a person responsible for their safety.
- This appliance is filled with a precise quantity of special oil. Repairs requiring the opening of the oil container are only to be performed by an authorised, qualified technician who should be contacted if there is an oil leakage.
- When disposing the appliance, follow the local regulations concerning the disposal of oil.



WARNING: In order to avoid overheating, do not cover the appliance.

- Do not use the appliance with a programmer, timer or any other device that switches the appliance on automatically. A fire risk exists if the appliance is covered or positioned incorrectly.

SPECIFICATIONS

Power supply : 230V~ 50Hz
Power Consumption : 700W
No. of Fins : 7

Specifications and features may change without prior notice.

NOTE: If you require a replacement for any of the items listed below, please quote their corresponding part numbers:

Replacement Part	Part Number
Front Foot	AI1117H08R
Rear Foot	AI1087H08R

Partmaster
CO.UK

Visit Partmaster.co.uk today for the easiest way to buy electrical spares and accessories.

With over 1 million spares and accessories available we can deliver direct to your door the very next day. Visit www.partmaster.co.uk or call 0844 800 3456 (UK customers only) Calls charged at National Rate.



This symbol on the product or in the instructions means that your electrical and electronic equipment should be disposed at the end of its life separately from your household waste. There are separate collection systems for recycling in the EU. For more information, please contact the local authority or your retailer where you purchased the product.

currys essentials

700W MINI OIL FILLED RADIATOR

INSTRUCTION MANUAL
C7MOR10



Thank You for purchasing your new Currys Essentials 700W Mini Oil Filled Radiator.


We recommend that you spend some time reading this instruction manual in order to fully understand all the operational features it offers.

Read all the safety instructions carefully before use and keep this instruction manual for future reference.

UNPACKING

Remove all packaging from the unit. Retain the packaging. If you dispose of it please do so according to any local regulations.

The following items are included:




The Main Unit



Front Foot
(P.N.: AI1117H08R)




Rear Foot
(P.N.: AI1087H08R)




Instruction Manual
(P.N.: C7MOR10-002)

If items are missing or damaged, please contact Partmaster (UK only).
Tel: 0844 800 3456 for assistance.

PRODUCT OVERVIEW




CONTROL PANEL




GB-1

ASSEMBLY

1. Unpack the radiator and remove all the parts from the packaging.
2. Place the radiator body upside-down on a scratch-free surface, making sure it is stable and will not fall.
3. Insert the front foot horizontally into the bottom of the front cover until it clips into place.



4. Insert the rear foot vertically along the rear fin and press it down until it is firmly fitted.



Do not operate without both feet attached. Only operate the radiator in an upright position (feet on the bottom, controls on the top), any other position could create a hazardous situation.

OPERATION

1. Position the radiator upright on the floor away from curtains, furniture or wallcovering before plugging your radiator into the mains socket.
2. Switch the **Power Switch** to the ON position.
3. Turn the **Thermostat Control** to the desired position. It is recommended to rotate to "MAX" position to get the radiator to pre-heat. It will take 5-10 minutes for the radiator to pre-heat.
4. When the room reaches the desired temperature, turn the **Thermostat Control** slowly anti-clockwise until the power indicator goes off with a "click" sound. The radiator will temporarily go off.
5. If the room temperature falls below the desired temperature, the radiator and power indicator will turn on again until the room temperature reaches the desired temperature.

GB-2


OVERHEAT PROTECTION SYSTEM

The power to the radiator will automatically cut off if the temperature of the heater exceeds a certain limit. In the event of overheating, the radiator will stop operating. Switch the radiator off and allow it to completely cool.

The radiator will then operate again as normal.

CLEANING AND STORAGE

1. Always remove the mains plug from the mains socket and allow the radiator to cool down before cleaning the radiator.
2. Wipe the radiator with a soft damp (not wet) cloth.
3. Store the radiator in a clean dry place.



Do not immerse the radiator in water. Do not use any cleaning chemicals such as detergents and abrasives. Do not allow the interior to get wet as this could create a hazard.

HINTS & TIPS

My radiator does not work when I turn it on

1. Check that your radiator is plugged in and the power is turned on at the mains socket.
2. Set the temperature to the highest setting.
3. Check if the thermostat setting is too low.
4. Try replacing the BSI or ASTS approved 13 Amp BS1362 fuse in the plug.
5. If the radiator still doesn't work, do not try to repair the radiator yourself.

If your radiator's power is automatically cut off follow the steps below:

1. Unplug your radiator and allow it to cool down.
2. Inspect your radiator.
3. Plug-in the radiator and switch it on again. If it cuts off again, move the radiator to a better ventilated location.
4. If there is any sign of physical damage (e.g. melting, or burning of the case), do not attempt to use your radiator. Please leave all maintenance work to qualified personnel.

GB-3